

# ACOUSTIC METAMATERIALS RESEARCH UPDATE, V2.1 NOVEMBER 16, 2017

ED STOKES, ECE PROFESSOR  
RYAN HILL, ECE GRADUATE STUDENT  
MATIAS MENDIETA, ECE UNDERGRADUATE STUDENT

# SINGLE RESONATOR EXPERIMENT

- **Change the Volume with water and keep everything else constant**

- **The Resonator's (Flask) cavity has a volume of  $V_{cav} \sim 47.78$  mL**



- **The Volumes that measurements were taken at**

- **1.) Empty (No Water)**
- **2.) 20 % of  $V_{cav}$  filled with water**
- **3.) 40 % of  $V_{cav}$  filled with water**
- **4.) 50 % of  $V_{cav}$  filled with water**
- **5.) 60 % of  $V_{cav}$  filled with water**
- **6.) 80 % of  $V_{cav}$  filled with water**
- **7.) 100 % of  $V_{cav}$  filled with water**


- $$f_{resonance} = \frac{c}{2\pi} \sqrt{\frac{S}{V(l+\Delta l)}}$$

- **$C$  = Speed of Sound in Medium**
- **$V$  = Volume of the Resonator Cavity**
- **$S$  = Cross Sectional Area of the Neck**
- **$l$  = Length/Height of the Neck**
- **$\Delta l$  = Neck Length Adjustment, based on whether the neck is flanged**
- ***Effective Length* =  $l + \Delta l$**

# SINGLE RESONATOR LAB SETUP



# SINGLE RESONATOR RESULTS, V2





# SINGLE RESONATOR RESULTS, V2

<b>% of Cavity filled w/ Water</b>	<b>Cavity volume</b>	<b>Calculated Resonance Frequency</b>	<b>Measured Resonance Frequency</b>
<b>0 %</b>	100%	175 Hz	187 Hz
<b>20 %</b>	80%	196 Hz	206 Hz
<b>40 %</b>	60%	226 Hz	234 Hz
<b>50 %</b>	50%	248 Hz	254 Hz
<b>60 %</b>	40%	277 Hz	282 Hz
<b>80 %</b>	20%	392 Hz	387 Hz
<b>100 %</b>	0%	N/A (INF)	459 Hz

# MULTIPLE RESONATOR THEORY

- Hybrid Resonance at  $f_0 = (f_{HR2} - f_{HR1}) / 2$



Sound Absorption Structures:  
From Porous Media to Acoustic  
Metamaterials


By Min Yang and Ping Sheng

Published In: *The Annual Review of Materials Research*

Annu. Rev. Mater. Res. 2017. 47:83–114

# MULTIPLE RESONATOR DESIGN, V2


## Front View



~6cm

~4cm

## Back Side View





# FUTURE TASKS

- Confirm the remaining Comsol Model (Single Resonator w/ Flow)
- Finish the Coupled Resonator w/ Flow Comsol Model
- Create a Coupled Resonator Setup with the physical Model
- Test the Physical Model
- Print the Multiple Resonator Model and test the model